



How to Fit a Pro Secure Handle

Our Pro-Secure security handle is non-handed.

When you take it out of the box you simply spin the handle into the correct orientation.

To remove your existing handle simply remove the two fixings screws on the inside of your door and gently remove the existing handle.

Then position your security handle over the same holes and fasten together with the hardened M6 security screws provided.